




IT8.7/3




ANSI (American National Standards Institute), a U.S. member of the International Standards Organizations (ISO) that develops voluntary standards for business and industry. IT8 is a set of standards developed by the ANSI committee governing color communications and control specifications (Romano). IT8 standards cover RGB, CMYK, scanning targets, and multivendor calibration (Romano).

An IT8.7/3 target is a printed reflection target that can be used to obtain the color gamut achievable by the fingerprint test. The target can be read by either a colorimeter or by a spectrophotometer. Many devices exist today that will even automate the process of reading and interpreting the target generating a color profile of the achievable color gamut for each fingerprint test. These color profiles are governed by the ICC (International Color Consortium). They can be attached to color halftone files thus optimizing the color balance of the printed halftone itself for a particular fingerprint. Color profiles have helped to attain consistency within the printing process by permitting predictable color reproductions. *It is very important to understand that a separate profile is created from each fingerprint. Failure to utilize the appropriate profile, may result in unpredictable print.* If used correctly, ICC color profiles can be a powerful tool aiding all types of printers.

1. Romano, Richard & Frank: *The GATF Encyclopedia of Graphic Communications*, GATF Press, 1998: p. 30.



Tone Scales



Tonal Range is defined as the range of halftone dots that can be printed. More specifically, it represents the highlight to shadow range that can be printed as determined by the fingerprint test. The tonal gradation information gained from the fingerprint test will ultimately influence the initial scanning stage of the reproduction and all subsequent halftone images. These tone scales can be read using a reflection densitometer that evaluates the dot area percentage as a percentage of the solid which is in question.


Conventional (AM) screen ruling breaks an image into different sized dots at a fixed angle with centers equally spaced. These dots are measured in the number of dots per inch (dpi) or lines per inch (lpi). AM screening is currently the most often used, and requires the least amount of computing power when outputting to film.

Stochastic (FM) screening breaks an image into the same sized spots in a random distribution. These spots are measured in microns (µm). Stochastic screening has helped eliminate moire and control abrupt tone breaks in graduated screen tints or vignettes.



85 lpi

Gray Balance

80 μ m


Gray is a color lacking a hue (also called achromatic color), or possessing all the wavelengths of light in equal amounts so that none predominates. (Romano, 1998). Grays are produced by the mixture of pigments. The subtractive colors, *cyan*, *magenta*, and *yellow* (CMY) combine to produce a neutral gray.

Gray balance is the proper percentage of combinations of cyan, magenta, and yellow inks that produce neutral shades of gray. Hue (color) shifts will occur when there is any imbalance of one of the components. It is necessary that every printer determine their gray balance for each combination of these components at specific line rulings. This is obtained by using gray balance targets as shown left and right. The targets represent only five different dot percentages, a chosen highlight (HL), quarter tone, midtone, three quarter tone, and shadow dot (SH). *Note: More than five gray balance blocks can be used for a fingerprint.* The actual number of blocks used depends upon how much information is needed about different neutral gray dot percentages.

Using a densitometer, a neutral gray patch for each dot percentage can be recorded. This information is then used by the prepress department to set neutral gray control points for each half-tone image. Knowing the neutral gray control points will ensure more consistent gray balance in printed reproductions.

The gray balance will vary for each different ink set as well as the same ink set over time. Therefore, it is recommended that the prepress department develop an upper and lower control limit around the average gray balance information. This will be the range the pressman must fall within while printing. It is further recommended that gray balance tests be repeated over time with the same ink set if it has not been used for an extended period of time.

1. Romano, Richard & Frank: *The GATF Encyclopedia of Graphic Communications*, GATF Press, 1998: p. 368-9.







Control Targets



Printability Targets



Resolution Targets
(Line Thickness Targets)



Control targets can be any target that is designed to provide information about specific printing characteristics. Usually, these targets are developed according to the type of printing process and press being used.

Printability Targets

Both positive and reverse point size targets for type are used to control the minimum size of type printable by the fingerprint test.

Resolution Targets

Targets used for determination of achievable line thicknesses. The prepress department will use the information from these targets to determine the absolute minimum line, both positive and reverse, that can be achieved when printing.

Modified Tone Scales

Other control targets consist of modified tone scales. These are used when there is limited space on the printed sheet. These control points can be used by the press operator to quickly monitor solid ink densities (SIDs) and dot gain (bottom corners). The press operator can then adjust the press according to the indicated condition of the printed sheet. It is a good idea to include tone scales with different screen rulings for a comparison.

Bar Codes


Bar codes have a preset value and are used for pass/fail evaluation of bar code printing. They also relay information about distortion and impression.



Printability Targets



Resolution Targets
(Line Thickness Targets)







Impression & Register






Color


The Electromagnetic Spectrum



"I drink my **RC** in my **GM** down **BY** the river!"
Dr. Sam Ingram



Subtractive Color Theory
(printing inks)



Additive Color Theory
(TVs & monitors)